


User Instruction Manual

Wire Form Anchors



Part Numbers:

RL-141; RL-142; RL-143

ISO 9001: 2008 Registered
Manual 103-0067



General Safety Information

Under Penalty of Law

- This *User Instruction Manual* is not to be removed except by the user of this equipment.
- Current *User Instruction Manuals* must always be available to the user.
- Read and understand these instructions before using equipment.
- ***Do not throw away these instructions.***



WARNING

Misuse or failure to follow warnings and instructions may result in serious personal injury or death.

Users must read and understand the *User Instruction Manual* provided with the product and be properly trained by their employer prior to use per OSHA 29 CFR 1910.66 and 1926.503 or applicable local standards.

Compliant fall protection and emergency rescue systems help prevent serious injury during fall arrest.

For instructions about proper use, refer to supervisor, *User Instruction Manual*, or call Rigid Lifelines at: 844-467-4443.

Purpose

Rigid Lifelines® Wire Form Anchors are designed to be used as part of a personal fall arrest system to help limit the forces associated with fall arrest.

Instructions For Use

- Failure to follow all instructions and limitations on the use of this equipment may result in serious personal injury or death.
- Before using a personal fall arrest system, employees shall be trained in accordance with the requirements of OSHA 29 CFR 1910.66 in the safe use of the system and its components.
- Prior to each use, inspect all personal fall arrest system equipment for wear, damage, and other deterioration. Defective components must be removed from service **immediately** in accordance with the requirements of OSHA 29 CFR 1910.66 and 1926.502.
- Thoroughly evaluate and plan all elements of your fall protection system(s) before using your equipment. Make sure that your system is appropriate for your needs and facility. Also be sure to calculate fall clearance and swing fall clearance.
- Users must have a rescue plan and the means to implement it. This plan must provide prompt employee rescue or assure that employees have the ability to rescue themselves in the event of a fall.
- Store this equipment in a cool, dry, and clean environment that is out of direct sunlight when not in use.
- After a fall occurs, this equipment must be removed from service and destroyed immediately.

Limitations For Use

- Rigid Lifelines Wire Form Anchors are designed for single users only.
- Per OSHA's 29 CFR 1910.66 and 1926.502 Rigid Lifelines Wire Form Anchors must only be used on structures capable of supporting at least at least 5,000 pounds (22.2 kilonewtons) per employee attached, or shall be designed, installed, and used as part of a complete personal fall arrest system which maintains a safety factor of at least two under the supervision of a qualified person.
- This equipment is designed to be used in temperatures ranging from -40°F to +130°F (-40°C to +54°C).
- Do not expose this equipment to chemicals or harsh solutions that may have a harmful effect. Contact Rigid Lifelines with any questions.

- Use caution when working with this product near moving machinery, electrical hazards, sharp edges, or abrasive surfaces, as contact may cause equipment failure, personal injury, or death.
- Minors, pregnant women, and anyone with a history of back and/or neck problems should not use this equipment.
- Do not use or install equipment without proper training from a “Competent Person,” as defined by OSHA 29 CFR 1926.32(f).
- Only Rigid Lifelines, or entities authorized in writing by Rigid Lifelines, shall make repairs or alterations to the equipment.

Connection Compatibility Limitations

All Rigid Lifelines® equipment must be coupled to compatible connectors. OSHA 29 CFR 1926.502 prohibits snap hooks from being engaged to certain objects unless two requirements are met:

1. It must be a locking type snap hook.
2. It must be “designed for” making such a connection.
 - a. “Designed for” means that the manufacturer of the snap hook specifically created the snap hook to be used to connect to the equipment in question.

The following conditions can result in rollout* when a non-locking snap hook is used. **Avoid the following connections:**

- Direct connection of a snap hook to horizontal lifeline.
- Two (or more) snap hooks connected to one D-ring.
- Two snap hooks connected to each other.
- A snap hook connected back on its integral lanyard.
- A snap hook connected to a webbing loop or webbing lanyard.
- Improper dimensions of the D-ring, rebar, or other connection point in relation to the snap hook dimensions that would allow the snap hook keeper to be depressed by a turning motion of the snap hook.




* Rollout: A process by which a snap hook or carabiner unintentionally disengages from another connector or object to which it is coupled. (ANSI Z359.0-2007)

Performance

All Rigid Lifelines® Wire Form Anchors meet a 5,000 pound tensile strength when statically tested in accordance with the requirements of the ANSI Z359.1-2007 standard.

Installation

1. Squeeze handle together to open the top section of the Wire Form Anchor and slip over structure.
2. Rotate handle to allow the circular part of clamp to position itself around the structure.
3. Release the handle to allow the hooks to engage on each side.



Installation Requirements

- Wire Form Anchors must be installed on structures capable of meeting the anchorage strength requirements of OSHA 29 CFR 1910.66 and 1926.502.
- Do not use the Wire Form Anchor on angled structures or at the end of a run where it could slide off the end of the structure.
- Do not use the Wire Form Anchor where loading is offset to the center of the Wire Form Anchor.

Inspection

All Wire Form Anchors must be inspected prior to each use. Annual inspections must be performed by an OSHA defined “Competent Person” other than the user.

If inspection reveals any defect, inadequate maintenance, or unsafe condition, remove from service immediately.

Any equipment that has been subjected to the forces of arresting a fall must be removed from service immediately.

Note: Only manufacturer, or entities authorized in writing by the manufacturer, may make repairs to the product. Otherwise, equipment must not be altered in any way.

Frequency

All equipment must be inspected prior to each use according to the manufacturer’s instructions. Annual inspections must also be performed by an OSHA defined Competent Person other than the user. All equipment should be inspected by a Qualified Person on a regular basis.

All equipment must be free of corrosion, chemical attack, alteration, excessive heating, or extreme wear.

All markings must be legible and attached to the equipment.

Cleaning And Maintenance

No cleaning or maintenance is required for this product. If inspection reveals any defect, remove from service and destroy **immediately**.

Part Number	Material	Length	Width	Connection Opening	Min. Tensile Strength	Approx. Weight	Regulation
RL-141	Stainless Steel	16 in.	5.6 in.	2-3 in.	5,000 lb.	0.8 lb.	OSHA 1910.66 OSHA 1926.502
RL-142	Stainless Steel	16 in.	6.8 in.	3-4 in.	5,000 lb.	0.9 lb.	OSHA 1910.66 OSHA 1926.502
RL-05	Stainless Steel	16 in.	8.0 in.	4-5 in.	5,000 lb.	1 lb.	OSHA 1910.66 OSHA 1926.502

Training

Employers are responsible for providing training to any employee who may be exposed to fall hazards. Training will enable an employee to recognize and reduce fall hazards. Training must be conducted by a Competent or Qualified Person. Trainer and trainees must not be exposed to fall hazards during the training course.

Service Policy

1. Obtain as much information as possible concerning the problem through personal observation by yourself or other authorized personnel familiar with the job and equipment: include model, serial and/or part numbers, voltages, speeds, and any other special identifying features. Be prepared to discuss the situation in detail.
2. All authorized labor charges will be based on straight time. Hourly rates, estimated man hours, and not to exceed total dollar amount required for corrections are to be agreed upon before authorization is given. There will be no allowances for overtime except in dire emergencies and then only with prior approval.
3. A verbal agreement may be reached immediately on both the method of correction and the approximate cost. A warranty authorization number will be assigned for the specific incident. A confirming written authorization will be forwarded to the distributor.
4. The distributor must send an itemized invoice, showing our release number or invoice number and warranty authorization number after authorized corrections have been made. A credit memo will be issued by accounting after the invoice has been received and approved. Warranty charges ARE NOT to be deducted from outstanding open account invoices under any circumstances.
5. Any field corrections made prior to an authorization by Rigid Lifelines will not be accepted as a warranty charge or the responsibility of Rigid Lifelines. Any modification to the equipment made without prior approval of the seller will void all warranties. A verbal authorization for modification may be obtained, in which event a warranty authorization number will be assigned for the specific modification. A confirming written authorization will be forwarded to the distributor.

One-Year Equipment Warranty

Rigid Lifelines warrants all Rigid Lifelines® fall protection soft goods, devices, connectors, and accessories to be free from defects in material and workmanship for a period of one (1) year, commencing on the date of shipment to the first retail purchaser ("Purchaser").

Rigid Lifelines is dedicated to offering superior service and quality products to all of our customers. If you would like to contact a customer service representative, please call the following number: 1 (844) 467-4443. We will be happy to assist you in any way that we can.

These warranties do not extend to equipment which has been subject to misuse, use in excess of rated capacity, negligent operation, use beyond Rigid Lifelines published service factors, improper installation or maintenance, adverse environments, and does not apply to any equipment which has been repaired or altered without Rigid Lifelines written authorization. This warranty is void for any product that is designed to deform or absorb energy during a fall event and needs to be replaced after a fall event has occurred.

Written notice of any claimed defect must be given to Rigid Lifelines within thirty (30) days after such defect is discovered. Rigid Lifelines obligation, and Purchaser's sole remedy under this warranty is limited to, at Rigid Lifelines discretion, the replacement or repair of the equipment at Rigid Lifelines factory or at a location approved by Rigid Lifelines. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES WHATSOEVER WHETHER EXPRESS, IMPLIED, OR STATUTORY. SELLER MAKES NO WARRANTY AS TO THE MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE EQUIPMENT AND MAKES NO OTHER WARRANTY, EITHER EXPRESS OR IMPLIED.

Rigid Lifelines shall not be liable, under any circumstances, for any indirect, special, or consequential damages including (but not limited to): lost profits, increased operating costs, or loss of production. This warranty shall not extend to damages including (but not limited to): lost profits, increased operating costs, or loss of production. This warranty shall not extend to any components or accessories not manufactured by Rigid Lifelines (example: casters), with the exception of the components, systems, or accessories involved with XSPlatforms, and purchaser's remedy for such components and accessories shall be determined by the terms and conditions of any warranty provided by the manufacturer of such components and accessories.



Rigid Lifelines
730 Hemlock Road, Suite 104
Morgantown, PA 19543

Toll Free: (844) 467-4443
Local: (610) 286-8030
Fax: (610) 286-6408

RigidLifelines.com
info@rigidlifelines.com